



## STEEL AND POLYPROPYLENE VENTILATION VALVES

UV  
SERIES

### OVERVIEW

#### TECHNICAL DATA

Air extraction valve with external frame and fine adjustable central body. Mounting frame for duct installation with joint.

#### MATERIALS

Frame and central part manufactured from sheet steel, painted white RAL 9010 (epoxy powder treatment).

#### MOUNTING FRAME

Installation by screws on lateral side fixed directly on duct joint or on wall.

#### MOUNTING VALVE



by fixing on the mounting frame.

#### CALIBRATION

Manual.

#### UNSUITABLE ENVIRONMENTS

The products in painted carbon steel are not suitable for installation in environments with high humidity and in environments with a potentially explosive atmosphere or containing powders or vapors of corrosive substances.



UVE	Valve sizes				Collar sizes		Weight
D <sub>nom</sub> [mm]	Ø A [mm]	Ø B [mm]	C [mm]	Ø F [mm]	Ød [mm]	ØD [mm]	P[kg]
80	115	61,5	42	77,5	79	105	0,15
100	138	75	40	97,5	99	127	0,21
125	164	99	46	122,5	124	155	0,295
150	202	119	50	147,5	149	176	0,41
160	211	129	54	157,5	159	186	0,46
200	248	157	63	197,5	199	230	0,62




# STEEL AND POLYPROPYLENE VENTILATION VALVES


## PERFORMANCE

## UV SERIES


### UV-80




### UV-100




### UV-125




### UV-150



### UV-160



### UV-200





## STEEL AND POLYPROPYLENE VENTILATION VALVES

UVP  
SERIES

### OVERVIEW

#### UVP - POLYPROPYLENE VALVES

##### TECHNICAL DATA

Extraction valve with valve body and adjustable central element.

##### MATERIALS

White RAL 9010 polypropylene,,

##### FIXING OF THE RING





With frontal screws.

##### FIXING OF THE VALVE

Plug in the ring.

##### CALIBRATION :

Manual,



Size	A	B	C	D	E	F
100	99	96	152	146	120	116
125	124	121	177	171	145	141
150	149	146	202	196	170	166




# STEEL AND POLYPROPYLENE VENTILATION VALVES



PERFORMANCE

UVP  
SERIES

UVP Ø100



UVP Ø125






# STEEL AND POLYPROPYLENE VENTILATION VALVES



PERFORMANCE

UVP  
SERIES

**UVP Ø150**



**UVP Ø200**













## STEEL AND POLYPROPYLENE VENTILATION VALVES

UVP  
SERIES

### INSTALLATION



- 1 Pose the mounting ring on the ceiling and secure it with screws
- 2 Draw a circle tangent to the three lugs (diameter F in the dimensional drawing)
- 3 Cut the counterceiling
- 4 Take out the duct and secure it to the neck of the valve
- 5 Insert the valve into the ring
- 6 Hook the valve with a clockwise rotation
- 7 Screw the central plate
- 8 Adjust the plate according to the required flow rate

